Hot Knife

3628 E. US 20 Rolling Prairie, IN 46371
Phone/Fax (219) 778-2325 www.waxconnections.com

!!!!!!!!!!!!!!!!!!!!!!!!!!!!WARNING!!!!!!!!!!!!!!!!!!!!!!!!!!!!

Safety Precautions:

- Never leave Hot Knife unattended, possible fire hazard.
- Tip will become very **HOT**. It will catch paper, wood or other flammable materials on fire.
- Handle to unit will become warm with time, to reduce turn low setting down and use high setting with foot switch to heat to your require temperature .
- Low setting should be turned down to lengthen life of tool.
- Wax Connections is not liable for damages resulting in the misuse of our products.

Hot Knife Controls:

- Power switch
  -The rocker switch on the right side of the unit.
- When main power is on the Red LED is illuminated.
- The Low, and High knobs are rotary switches
  - Rotate these knobs clockwise to introduce more heat
- The **Low** setting controls the temperature of the knife at an idle position
- The **High** setting controls the temperature of the knife when the foot pedal is pressed.
- The foot pedal connects to the unit in the rear.
- Unit will not operate without foot switch.